Videos

Dr Frazer Noble

Introduction

In this presentation, I will describe:

• How to use OpenCV to get frames from a video source.

Requirements

To follow along with this tutorial, you will need the following tools:

- Python 3.8.6.
- Visual Studio Code 1.53.1.

You will also need to install the following Python packages:

- OpenCV.
- NumPy.

It is assumed that you are using Windows; however, these instructions should be easily adapted to Linux.

Getting Started

Open Visual Studio Code. To open the app: Open the Start menu, type Visual Studio Code, and then select the app.

Open the Explorer tab. To display the tab: Left click View > Explorer or press ctrl + Shift + E. This will display the Explorer tab.

Left click on the Open Folder button. This will display the Open Folder prompt. Browse to the following directory:

C:/Users/%USER%/Documents

Note: Replace %USER% with your own username. My username is fknoble; hence, the path is C:/Users/fknoble/Documents.

In C:/Users/%USER%/Documents create a new folder named opencv_05. To create a new folder: Right click in the Explorer tab, left click New Folder, and rename it.

In C:/Users/%USER%/Documents/opencv_05 create a new file named video.py. To create a new file: Right click on /opencv_05 in the Explorer tab, left click New File, and rename it. The file will open automatically.

/opencv_05 should contain the following files and folders:

/opencv_05
 video.py

video.py

Type the following code into video.py:

```
import cv2 as cv
import numpy as np
```

OpenCV's Python module cv2 is imported as cv and NumPy's Python module numpy is imported as np .

Type the following code into video.py:

```
def main():
    camera = cv.VideoCapture(0)

    if not camera.isOpened():
        print('ERROR::CV::Could not open video device.')
        return 1
```

This begins main() 's definition. VideoCapture(0) creates a VideoCapture object using the default device and assigns it to camera. If the object is not open, a message is displayed and main() returns 1.

Type the following code into video.py:

```
while True:
    ret, frame = camera.read()
    if ret is True:
        cv.imshow("frame", frame)
    i = cv.waitKey(30)
    if i == 27:
        break
cv.destroyAllWindows()
return 0
```

camera 's read() requests a frame from camera. If a frame is retrieved, it is saved in frame and ret is assigned True. If ret is True, frame is then displayed in the window. waitKey() waits for input. If so is pressed, the loop ends.



Figure: The frame array.

Type the following code into video.py:

```
if __name__ == '__main__':
    main()
```

main() will be called when the video.py is run.

Run video.py

Open a new terminal in Visual Studio Code. To open a new terminal: Left click View > Terminal or press [tr] +].

Type the following commands into the terminal and then press ever after each one:

```
cd ./opencv_05
python video.py
```

This will change the current directory to the /opencv_05 sub-directory and then run video.py.

Press any key to close the windows and stop video.py.

Conclusion

In this presentation, I have described:

• How to use OpenCV to get frames from a video source.

References

1. https://docs.opencv.org/.